



Autonet Mobile GPS Navigation Receiver

There are only a few simple steps that you need to follow before using your GPS receiver.

1. Select a mounting location in the vehicle where the GPS Receiver will be secure and not obstruct normal driving, visibility and safety, but still maintaining a “view to the sky” in order to receive the satellite data.
2. Plug the USB connector on the GPS receiver into either of the USB ports of your Autonet Mobile router.
3. Reset or power cycle your Autonet Mobile router

LED OFF: GPS receiver is off (no power)

LED ON (solid): No fix, searching for GPS signals

LED Flashing: Position fix established and GPS signals are being received

The first time that you operate the GPS it may take a few minutes to fix a position depending on various factors such as the distance of the current coordinates from the last time the GPS receiver was activated, GPS signal strength and surrounding terrain (tall trees and buildings can block the satellite signals).

FCC Notice

Federal Communication Interference Statement

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and radiates radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures: reorient or relocate the receiving antenna. Increase the separation between the equipment and the receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an authorized radio/TV technician for help.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth in an uncontrolled experiment. This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions.

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

FCC Caution

To assure continued compliance use only shielded interface cables when connection to any device. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

